

## How to start two-way audio between IPC and Client

### Description

HIKVISION cameras with -S in their names support audio function, for these kind of cameras you can get not only the live video but also the real-time audio. Two-way audio could be used for only **one camera at one time**.

#### *Note:*


1. Some camera like DS-2CD2412F-I (W) has internal microphone and speaker; however, for most of HIKVISION cameras, external microphone and speaker are required.
2. Two-way audio could only be realized between IPC and client, like between 4500 client and IPC, 4200 client and IPC, not between IPC and IPC or client and client.

### Preparation


- 1, cameras which support audio function
- 2, external microphone & speaker
- 3, client like iVMS-4200 & iVMS-4500

## How to plug external microphone & speaker to IPC

1. HIKVISION cameras have different audio interface. Below are two examples.  
(1) **21XX Network Camera**. In this picture below, the audio interface is 11.



(2) **63XX Network Camera.** In this picture below, the audio in interface is 9 and the audio out interface is 10.



2. Plug **microphone** to the **audio in interface** and plug **speaker** to the **audio out interface** would be OK.

3. Microphone doesn't require a power supply while sound pickup needs. As to the detailed differences, please kindly check the table below.


## Microphone vs Pickup

Comparison	Microphone	Pickup
Interface	MicIn	AudiIn or LineIn
Direction	Unidirectional	Omnidirectional
Quality	Not good	Good
Sensitivity	Low	High
Power	Passive	Active
Application	Shop, ATM, etc.	Law enforcement

## How to start two-way audio via web

### Steps:

1. Login you camera via web;
2. Enable the audio output as well as the two-way audio by clicking the buttons shown in the yellow circles below. The **Red Microphone icon** means two-way audio is **ON**.



## How to start two-way audio via iVMS-4500

### Steps:


1. Add your camera to 4500 client;

2. Click the microphone to enable two-way audio.  means it is disabled.




## How to start two-way audio via iVMS-4200

1. Add your camera to 4200 client;
2. Go to Main View, enable the **Audio Output**, then right click your mouse in the live view interface and select **Start Two-way Audio**.



3. If you add your IPC to NVR and this NVR is added in iVMS-4200 client, you need to select the **Start IP Two-way Audio** to speak to your IPC. If you select **Start Two-way Audio**, you will speak to the NVR.



**First Choice for Security Professionals**

**HIKVISION Technical Support**