How to Configure VLAN on Smart Managed Switch

How to Configure VLAN on Smart Switch

Preparation

Switch: DS-3E1510P-SI, or SI series Smart Managed Switch.

Login Webpage

# Create VLAN

Click the Add to create a VLAN ID; the range of parameter is 1-4094.

Port Type

Divide the port into the VLAN which is created. At the Port Configuration page, select the port, for example the Ge1. And click the Edit.

Access Port

In general, the Access Port is used to connect the terminals, and it need to configured PVID which means this port is divided into this VLAN.

Trunk Port

In general, the trunk port is used to connect switch. the PVID is vlan 1 by default, the parameter VLAN allowed to be accessed means whether to transmit the data bring the VLAN ID or not.

Save

Click this button to save configuration.

See Far, Go Further